



Setup and Handling of Ultra-Containment Berm® Collapsible Wall Model

The rugged construction of the Ultra-Containment Berm, Collapsible Wall Model offers excellent chemical resistance and durability. To ensure the longest life and most effective use of the Ultra-Containment Berm, setup and handling are key.

The following guidelines are provided to ensure that you get the best results.

DEPLOYMENT:

- 1) Select a level area and be sure that ground is swept clean of debris and sharp objects. The use of a ground cloth is recommended.
- 2) Place the folded Berm at the setup location. Do not drag the folded Berm. Unfold Berm and position as desired. Position the frame legs facing toward the inside of the Berm.
- 3) If tread protectors are being used, place these in the unit at this time.
- 4) The Berm is now ready for use.

STORAGE:

- 1) Sweep out Berm and be sure that it is dry and free of contaminants.
- 2) Store unit in clean dry environment.

REPAIR AND MAINTENANCE

- 1) If a puncture or tear occurs, call for a patching kit. Describe the damage to the service representative to ensure receipt of the proper kit.
- 2) Replacement frame assemblies are available from your dealer.

MISCELLANEOUS

- While the Berm will perform properly with liquids reaching the top of the wall, it is suggested that the recommended fill line not be exceeded. The fill line is 1" below the top of the Berm. A Berm that is filled to the top edge of the wall is subject to splash over in the event of wind or being bumped etc.
- Feel free to contact UltraTech International direct at 1-800-353-1611 for further information.